


**Dimmer time switch
AlphaLux³ D21**


4126 26 / 27



⚠ Safety notes

This product should be installed in line with installation rules, preferably by a qualified electrician. Incorrect installation and use can lead to risk of electric shock or fire. Before carrying out the installation read the instructions and take account of the product's specific mounting location. Do not open up, dismantle, alter or modify the device except where specifically required to do so by the instructions. All Legrand products must be opened and repaired exclusively by personnel trained and approved by Legrand. Any unauthorised opening or repair completely cancels all liabilities and the rights to replacement and guarantees. Use only Legrand brand accessories.

The device contains a LiMnO₂ primary cell. When the product reaches the end of its life, this cell must be correctly removed and disposed of in accordance with national legislation and the requirements of environmental protection.

Technical data	4126 26	4126 27	
Supply voltage	230 V 50/60 Hz	120 V 50/60 Hz	
Effective power consumption	ca. 1 W		
Contact rating: Parallel compensation	1 changeover contact 16 A 250 V~ $\mu \cos \varphi = 1$ 600 W max. 70 μF		
Accuracy	~ 0,1 s / day		
	single strand	multi strand	 max. 1,4 Nm
	1,5...4 mm ²	1,5...2,5 mm ²	
Programmes	56		
Battery reserve	5 years		
Control line length	max. 50 m		
Delay	30 ... 300 s		
Switching threshold	1 lx ... 100 klx		
	-20° C ... +60° C		-20° C ... +60° C
	-20° C ... +55° C		-20° C ... +70° C
IP:		IP:	65

General information

Start-up: after applying the supply voltage, the time switch starts automatically with the last selected function. The relay position is set by the current program.



A program must be set in order for the device to function



Select menu, back to main menu,
Hold down > 1s = operating display




Confirm selection or load parameters





Select menu options or set parameters
For operating indicator: Display of lux value.




Select menu options or set parameters.
For operating indicator: Display of next switch time




Operating principle: Typ 1.B. S. T.
 IEC/EN 60730-1, IEC/EN 60730-2-7
 Montage (time switch): in distribution panel,
 Degree of contamination: 2
 Switch output, potential-free
 Rated impulse voltage: 4 kV

			
4000 W	2000 VA	600 W 70µF	2000 W
			
2000 W	2000 W	2000 W	1000 W
			 LED
			1000 W

Overview



1 Set language




2 Set time/date, summertime/wintertime


Summertime: ± 1 hour

Europe: Factory set

SPECIAL: The switchover to/from summertime can be freely programmed by entering a start date and end date and is then executed each year on the same day of the week, e.g. Sunday




2 Settings for brightness-dependent switching



The delay time prevents switching back and forth when brightness and darkness change quickly (e.g. clouds passing by). The default setting is 90 seconds. The setting range is from 30 to 300 seconds.

The time switch compares the brightness value measured at regular intervals to the set switch-on and switch-off threshold. If the set brightness value drops below the set switching threshold, the time switch switches on the connected light sources. If the set brightness value exceeds the set switching threshold, the time switch switches off the connected light sources. The switching thresholds can be set separately between 1 lx and 100 klx.

3 Programming



A program must be set in order for the device to function.

	Switching on	Switching off
1	Time 19	Time 19
2	Brightness 0	Brightness *
3	Brightness + Time 0 + 19	Brightness + Time * + 19
4	Brightness 0	Time 19
5	Time 19	Brightness *


A program consists of an ON time, OFF time and associated on and off days.

Programs with predefined on/off days Mon to Sun. For this program, you only need to set the switching times.

With the „INDIVIDUAL” option, you can allocate switching times to specific days of your choice.

The programs of a channel are combined with a logical OR.



3 Programming



*
 CHRONO = All switch commands are executed in chronological order in a week
 INPUT = Programs are executed in the order in which they are entered


Programming examples

Switching on and off exclusively time-controlled





Select the appropriate symbol with the PLUS and MINUS keys:

-  Switching on in acc. with preset switch-on threshold
-  Switching off in acc. with preset switch-off threshold
-  ON/OFF at programmed time
-  +  /  +  Switching on / off in acc. with switch-on/off threshold in specified period



Switching on and off exclusively dependent on brightness




The time switch compares the brightness value measured at regular intervals to the set switch-on and switch-off threshold.



If the set brightness value drops below the set switching threshold, the time switch switches on the connected light sources. If the set brightness value exceeds the set switching threshold, the time switch switches off the connected light sources.

The switching thresholds can be set separately between 1 lx and 100 klx.





Within a specified switch-on/off time, the brightness determines the switching times






Switching on brightness-dependent, switching off time-controlled




4 Modes

- **Auto** - Automatic operation
- **Constant ON**
- **Constant OFF**
- **Extra**

The switch status imposed by the program is inverted (manual override).
With the next effective switch command, the time switch resumes control of on/off switching.



5 Contrast adjustment




6 1 h-Test

When this function is activated, the output is switched on for one hour.




After one hour, the time switch returns automatically to the programmed mode.

7 Data key



Load the programs of the time switch on to a data key (WRITE KEY)

Warning! all programs stored on the data key will be overwritten.




Load the programs from the data key to the time switch (READ KEY)

Warning! all programs programmed in the time switch will be overwritten.

8 Hour counter

Displays the total relay ON time, (0 to 65535 h) and the date of the last reset.



9 Random function

Function to simulate presence.


Function active: the programmed switching cycles are shifted at random within the range of ± 15 minutes.



10 Pincode


PIN CODE active: The menus of the time switch will not be accessible unless the PIN CODE has been entered. When the pin code is active, access to the button and key functions is disabled 1 minute after the last button press.

PIN free access can be re-enabled by selecting **PASSIVE** or by resetting the device.



11 Holiday

After activation the holiday program is executed between 0:00h on the start date and 24:00h on the end date (Constant ON/OFF). After the holiday program has run once, it must be reactivated.




12 Activating and deactivating grid synchronisation

The default setting is PASSIVE. In order to improve the long-term accuracy, it is advisable to activate synchronisation if the time switch is supplied from a on 50/60 Hz grid with frequency adjustment.




13 Cycle function

For cyclical switch commands the switching on time is set by logical "OR" of programs of all types. A fixed cycle of ON and OFF time then operates within those limits. The cycle always starts with the ON time. The cycle duration and the ON time within the cycle are the same length for all switching times. The cycle duration and the ON time can be set independently in one-second increments. If the switching time is shorter than the cycle duration, the cycle will be shortened accordingly. The ON time will remain unchanged. If the switching time is actually shorter than the ON time, the ON time will be shortened accordingly.



	min	max
Periode	2s	2h
Impuls	1s	1h 59min 59s



Inset box details:

- Small bar chart with three bars of increasing height.
- Digital display text:


```

      AUTO  LL
      TU 14:00:00
      01.NOV.2011
      
```



No sensor connected, cable break or short circuit

Reset


Warning!

The memory will be cleared,
and all set data will be lost.

Hold down **OK** for more than 3 seconds
and at the same time press and release



The language, time, date, summertime/
wintertime, delay time, switching thresholds
and switching times will have to be
re-entered.



Warning: Elektrical shock - Disconnect all power from the device before dismantling the module and replacing the battery.

Always use a Li cell type battery (LiMnO₂) CR2477, 3V
high temperature type min +85 °C

